


SAVE THESE INSTRUCTIONS

14. This appliance was designed for use over a glass aquarium cover or panel DO NOT USE OVER "OPEN" WATER.
 13. The appliance is intended FOR HOUSEHOLD USE ONLY.
 12. If an extension cord is necessary, a cord with a proper rating should be used. A cord rated for less amperes or watts than the appliance rating may over heat. Care should be taken to arrange the cord so that it will not be tripped over or pulled.
 11. Read and observe all the important notices on the appliances.
 10. Make sure an appliance mounted on a tank is securely installed before operating it.
 9. Do not install or store the appliance where it will be exposed to weather or temperatures below freezing.
 8. Do not use an appliance for anything other than its intended use. The use of attachments not recommended or sold by the appliance manufacturer may cause an unsafe condition.
 7. Always unplug an appliance from an outlet when not in use, before putting on or taking off parts, and before cleaning. Never yank the cord to pull the plug from outlet. Grasp the plug and pull to disconnect.
 6. To avoid injury, do not contact moving parts or hot parts such as heaters, reflectors, lamp bulbs, and the like.
 5. Close supervision is necessary when any appliance is used by or near children.
- is that part of the cord below the level of the outlet, or the connector if an extension cord is used, to prevent water travelling along the cord and coming into contact with the outlet.



1. If the appliance shows sign of abnormal water leakage, immediately unplug it from the power source. If the appliance falls into the water, DO NOT reach for it! First unplug it and then retrieve it. If electrical components of the appliance get wet, immediately unplug it.
2. Carefully examine the appliance after installation. It should not be plugged in if there is water on parts not intended to be wet.
3. Do not operate any appliance if it has a damaged cord or plug, or if it is malfunctioning or has been dropped or damaged in any manner.
4. To avoid the possibility of the appliance plug or outlet getting wet, position aquarium stand and tank to one side of a wall-mounted outlet to prevent water from dripping onto the plug or outlet. A drip-loop, shown in the figure here, should be arranged by the user for each cord connection to an outlet. The drip-loop

READ AND FOLLOW ALL SAFETY INSTRUCTIONS

DANGER: To avoid possible electric shock, special care should be taken since water is employed in the use of aquarium equipment. For each of the following situations, do not attempt repairs by yourself; return the appliance to an authorized service facility for service or discard the appliance.

IMPORTANT SAFEGUARDS



Interpet has applied over 65 years of aquatic experience to ensure every element of the design of this product has been carefully considered to help you enjoy aquarium keeping.

customercare@interpet.co.uk
Distributed by: Interpet Ltd. Vincent Lane,
Dorking, Surrey, RH4 3YX, England, UK

www.interpet.co.uk

Interpet is a registered trademark of Interpet Limited

Interpet

LED START PLUS Colour Change

Quick Start Guide



IMPORTANT SAFETY INSTRUCTIONS

SAVE THESE INSTRUCTIONS FOR FUTURE USE

INSTALLATION

Four options available for fitting the Start Plus LED

- Hood location with adhesive pads** – Attach the double sided adhesive pads to the flat surface of the LED. Fix the Start Plus LED to the underside of the hood in the desired location – ensure the hood surface is flat, clean and dry. DO NOT attach directly to fluorescent lamps or lamp reflectors.
- Hood location with screws** – Ensure the hood material is thicker than the length of the screws to prevent them from protruding through the outer surface. Place the Start Plus LED in the desired location under the hood. Using the self-tapping screws provided, fix the LED in position using the fixing holes in the LED.
- Hood location with glue** – Select desired location on the underside of the aquarium hood and mark the position of the LED. Keep the hood away from the aquarium while gluing the LED as the glue can be dangerous to the fish. Clean the marked area with a damp cloth then allow to dry, glue into the marked position on the aquarium hood.

An all-round plastic / wood glue is recommended for application. For example, a 502 super adhesive glue. Always follow the glue manufacturer's instructions.

- Submersed in Aquarium with suckers** – Attach suckers provided to the brackets by sliding the button on the sucker into the slot in the bracket (See image). Fit the bracket onto the Start Plus LED and place into desired location in the aquarium (ensure that the LED push fit cable socket is not submersed) press suckers onto glass (to optimize adhesion clean the glass before applying the sucker).

RECOMMENDED USE

Narrow and long aquariums for an even spread of light.



SAFETY INSTRUCTIONS

CAUTION:

- Before installation of this product, be sure to read and understand all safety instructions and warnings.
- Always unplug this product before any inspection or disassembling for any reason.
- DO NOT SUBMERSE THE PLUG OR CABLE SOCKET.

MAINTENANCE

Switch the Start Plus LED off and remove from the brackets – wipe off any dirt, salt mineral deposits with a damp cloth. Do not use cleaning agents that could enter the aquarium and harm your livestock.

- Do not attempt to dismantle the product other than the instruction above as this will void your warranty. The information below should be followed to keep the product in good condition.
- Read the manual carefully before operating the product. Make sure you use the product correctly.
- Only use the adapter supplied with the product.
- Do not pull or twist the power cord, or move the product by holding the power cord only, as this will damage the power cord.
- Make sure the power is disconnected before installing or cleaning.


Questions or need spare parts, please visit www.interpet.co.uk.

MULTI COLOUR INLINE CONTROLLER

Press to select from a wide range of lighting effects.


Press to choose a single fixed lighting colour.

On/off button – also control the speed of lighting effects.



BRACKET

Start Plus LED attachment bracket



Sucker button slot

GUARANTEE

This product is guaranteed as free from defects in materials and workmanship for a period of 1 year from the date of purchase. This guarantee covers only any defects caused during normal use and operation of the light, in accordance with the instructions enclosed.

It does not apply to any unauthorised modifications or misuse, improper or inadequate maintenance, or operations outside the product specifications. In case of defect within the stated warranty period, the product should be returned, with proof of purchase, to the point of purchase.

This guarantee does not affect your statutory rights. Guarantee service includes repair or replacement of the light at Interpet Ltd.'s discretion. Neither Interpet nor the manufacturer are liable for any direct, indirect, special, incidental or consequential damages, including loss of livestock, arising from a defect in this product.

Questions or need spare parts, please visit www.interpet.co.uk.

Interpet Customer Care Department

Interpet Ltd. Vincent Lane, Dorking, Surrey, RH4 3YX, UK

customercare@interpet.co.uk